


ELECTROMAGNETIC DOOR HOLDER DH-L65 INSTALLATION INSTRUCTION



Horizontal Fixing Position

User Manual

Application:

Fire Door or Escape Door

Normal Operation Method:

To ensure the door is held properly by the door holder, the door with armature must be pressed slightly against it.

During Emergency

- Security system will automatically cut off the powersupply to the door holder or ;
- Press the red button to release the door.

Testing


Manually press the red button on the top of the door holder to ensure the automatic door closing mechanism is working. Releasing the red button will recover the holding function.

Current Rating - 12 Volt - 80 mA
- 24 Volt - 40 mA

Holding Force - 50 kg

Connections - Terminal - Max 2.00mm wire cable

WIRING INSTRUCTION



IMPORTANT!

Set the jumper position according to the power input correctly before switch ON the power.

Copyright EBELCO Industries Sdn. Bhd.
All Rights Reserved. © 2022